



```
.measure tran avgleakagestk AVG i(vpstk) FROM='ckper+(cktr/2)' TO='ckper+(cktr/2)+(ckper/2)'
```

when $i(vpstk)$ is plotted the plot shows negative current. But I expect it to be positive (because current is flowing in to the source). Why do I see different from what I expected?

Initially “node” is high there is a leakage current flowing in to the source and PMOS is turned off also the the “node” voltage decreases and still the current is flowing in to the source.